


NEW HAY MOISTURE METER (Model : GMK-3308)

1. DESCRIPTION OF THE INSTRUMENT



2. BEFORE MEASUREMENT

- CONNECT SENSOR CABLE WITH THE INSTRUMENT.
- OPEN THE LID OF BATTERY COMPARTMENT (BACK SIDE) AND PLACE 9V BATTERY 1EA IN IT.
- 'F08' SIGN APPEARS ON LCD AND DISAPPEARS, THE INSTRUMENT IS READY TO MEASURE IN NOMAL CONDITION (AUTO CALIBRATION).

3. MEASUREMENT

- PREPARE FOR THE TEST SAMPLE AND PLACE AN INSTRUMENT AT THE SAME PLACE FOR ABOUT 10 MINUTES.
- INSERT SENSOR INTO THE HEAP OF HAY STRAIGHTLY.
- PRESS 'MEASURE' BUTTON, AND THE MEASUREMENT RESULT APPEARS ON LCD FOR ABOUT ONE MINUTE.
(# WHEN THE MOISTURE % OF THE TEST SAMPLE IS BELOW 12%, "ErL" SIGN APPEARS AND IN CASE OF OVER 41.5%, "ErH" SIGN APPEARS.)
- PRESS 'AVERAGE' BUTTON, AND YOU CAN GET THE AVERAGE DATA (UP TO 9 TIMES).
- PRESS 'AVERAGE' BUTTON ONE MORE TIME, THE POWER IS OFF.
- WHEN THERE IS NO OTHER OPERATION, THE POWER IS OFF AUTOMATICALLY AFTER 3 MINUTES (AUTO HOLD & AUTO OFF FUNCTION).

4. IMPORTANT

- DO NOT STORE THE INSTRUMENT AT DAMP PLACE.
- IN CASE OF NO USE FOR A LONG TIME, MAKE SURE TO REMOVE THE BATTERY.
- THE MANUFACTURER GRANTS A TOTAL REPLACEMENT WARRANTY OF 12 MONTHS AFTER THE DATE OF PURCHASE.
- IN CASE OF WRONG USE, ABUSE OR MISUSE, WARRANTY WILL NOT AVAILABLE.

G-WON HITECH CO., LTD.

WOOLIM E-BIZ. CENTER 310,
#170-5, GURO-DONG, GURO-GU,
SEOUL, KOREA(152-769)
Tel : 82-2-2108-1646(DIR.)
Fax : 82-2-2108-1649
E-MAIL: g-won@g-won.co.kr

Other Instruments

- | | |
|--------------------------|-------------------------|
| ■ Grain Moisture Meter | ■ Coffee Moisture Meter |
| ■ Tobacco Moisture Meter | ■ Digital Refractometer |
| ■ Flour Moisture Meter | ■ Digital Salt Meter |
| ■ Tea Moisture Meter | ■ Fruit Acidity Meter |

